DIGITAL SAFE GUIDE • GUÍA DE CAJA FUERTE

Ensuring your valuables remain safe & secure during your stay ♡

CONDOMINIUM
ART 28 MIRAFLORES
LIMA, PERU

FIXSER CD200-1 • 8 LITERS Electronic Keypad & Motorized Safe Panel

Factory Default User PIN: `1234`

1. LCD SCREEN
`OPEN`
Wakes on `#` • 2 Beeps

2. DIGITAL KEYPAD
`[ 1 2 3 ] [ 4 5 6 ] [ 7 8 9 ]`
Press `#` + PIN + `#`

3. KNOB & RESET
↻ Turn to Open • ↺ Turn to Lock
Green Button: Inside door near hinge

GB ENGLISH INSTRUCTIONS — STEP-BY-STEP

1 HOW TO OPEN SAFE — OPEN

1. Press `#` to wake the blue LCD display.
2. Enter your PIN (Default: **1234** or custom).
3. Press `#` again to confirm.
4. Display shows `OPEN` and beeps twice.
5. Turn knob **clockwise (↻)** within 10 sec & pull door.

2 SET YOUR PERSONAL PIN — DOOR OPEN

1. Keep the door **WIDE OPEN** throughout setup.
2. Press the **GREEN BUTTON** inside the door edge.
3. Screen displays dashed lines: `------`.
4. Enter your new code (**1 to 8 digits**, 4–6 recommended).
5. Press `#`. Screen displays `EN` (Entered).
6. **Test new PIN twice with door open** before closing!

3 HOW TO LOCK SAFE — LOCK

Close door completely, then turn knob **counter-clockwise (↺)**. Give knob a gentle tug to verify deadbolts are locked.

! DISPLAY ALERTS & LOCKOUT — SECURITY

- `HOLD`: 3 wrong codes lockout safe for 15 min. Please wait without touching buttons.
- `LOBATTE`: AA batteries low. Contact host immediately.
- Physical override key is held by host for emergencies.

PE INSTRUCCIONES EN ESPAÑOL — PASO A PASO

1 CÓMO ABRIR LA CAJA — APERTURA

1. Presione `#` para activar la pantalla digital.
2. Ingrese su código (Fábrica: **1234** o su clave).
3. Presione `#` nuevamente para confirmar.
4. La pantalla mostrará `OPEN` y sonarán 2 pitidos.
5. Gire la perilla a la **derecha (↻)** en 10 seg y abra.

2 PROGRAMAR SU CLAVE PERSONAL — PUERTA ABIERTA

1. Mantenga la puerta **ABIERTA** durante todo el proceso.
2. Presione el **BOTÓN VERDE** interior cerca a la bisagra.
3. La pantalla mostrará guiones: `------`.
4. Ingrese su nueva clave (**1 a 8 dígitos**, 4–6 sugerido).
5. Presione `#`. La pantalla mostrará `EN` (Guardado).
6. **¡Pruebe su clave 2 veces con puerta abierta!**

3 CÓMO CERRAR Y ASEGURAR — CIERRE

Cierre la puerta firmemente y gire la perilla hacia la **izquierda (↺)**. Verifique con suavidad que los pestillos de acero queden trabados.

! AVISOS Y BLOQUEO TEMPORAL — SEGURIDAD

- `HOLD`: 3 intentos fallidos bloquean la caja 15 min. Espere sin presionar botones.
- `LOBATTE`: Pilas AA agotándose. Avise a Silvia.
- La anfitriona tiene la llave de emergencia física. No forzar.

✓ CHECK-OUT REMINDER / RECORDATORIO DE SALIDA:
Please remove all your valuables and **LEAVE SAFE DOOR OPEN & UNLOCKED** upon departure. / Por favor retire sus pertenencias y **DEJE LA PUERTA DE LA CAJA ABIERTA** al retirarse.

Forgot code or need emergency key? WhatsApp Silvia: +1 (954) 907-5730
24/7 lobby concierge also available in building ground floor. We are here to assist you immediately!

♡ **THANK YOU FOR CARING FOR OUR HOME • ¡MUCHAS GRACIAS POR SU VISITA!**

SILVIA • LILY PAD VACATION RENTALS MIRAFLORES