LG WASHTOWER™ • GUÍA DE LAVADO Y SECADO

Quick Guest Operating Guide • Guía Rápida para Huéspedes • Model WK22WS6

CONDOMINIUM
GRIMALDO 247
MIRAFLORES, LIMA

SHARED CENTER PANEL — Top Drum: Dryer (11 kg max) • Center: Shared Panel • Bottom Drum: Washer (22 kg max)

⚠ WASH DRUM IS 2X DRYER CAPACITY • DO NOT OVERLOAD DRYER

DRYER CONTROLS (UPPER): Power ⏻ • Cycle Selector • Start/Pause ▶|| • Lint Trap

WASHER CONTROLS (LOWER): Power ⏻ • AI DD™ Normal • Start/Pause ▶|| • HE Drawer

GB ENGLISH INSTRUCTIONS — STEP-BY-STEP

1 POWER ON • SELECT DRUM — CENTER PANEL

The single center panel controls both machines. Press the **Power ⏻ button** for the unit you wish to use: **Washer** (lower buttons) or **Dryer** (upper buttons).

2 DETERGENT & SOFTENER DRAWER — HE DETERGENT

- **Liquid / Powder:** Pull open left drawer. Add HE detergent to the **Main Wash** cup (never exceed the **MAX** line). Add softener to the flower cup.
- **Laundry Pods:** Place pod **directly inside drum** before adding clothes. *Never put pods in the drawer!*

3 START WASH • AI DD™ SENSOR — AUTO SENSED

Load clothes and shut door firmly (clicks & auto-locks). Leave on **Normal (AI DD)**. The drum rotates briefly to weigh clothes & sense fabric softness, tailoring water & motion automatically. Press **Start/Pause (▶||)**.

4 DRYER • CAPACITY WARNING (11 KG) — MAX 2/3 FULL

The dryer drum is half the size of the washer. **Do not overload!** Never fill higher than the top two internal tumble paddles. If you washed a massive load, split it into two dryer cycles for fast, fluffy results.

5 LINT SCREEN • CLEAN EVERY LOAD — ESSENTIAL

Pull out the lint filter located inside the bottom rim of the dryer door. Swipe away lint with your fingers and push it firmly back down before starting. A clean filter prevents fires and cuts drying time in half!

6 LIMA HUMIDITY • PREVENT ODORS — LEAVE AJAR

Lima has high ocean humidity. When done, wipe down the grey rubber door gasket with a towel and **leave the lower washer door cracked slightly open (ajar)** so the drum vents and stays fresh.

PE INSTRUCCIONES EN ESPAÑOL — PASO A PASO

1 ENCENDIDO Y PANEL CENTRAL — PANEL CENTRAL

El panel central opera ambos equipos. Presione el botón de **Encendido ⏻** del tambor que usará: **Lavadora** (botones inferiores) o **Secadora** (botones superiores).

2 DISPENSADOR DE JABÓN Y SUAVIZANTE — SOLO HE

- **Líquido / Polvo:** Abra el cajón izquierdo. Vierta detergente HE en el compartimento principal (no pase la línea **MAX**). Agregue suavizante en la flor.
- **Cápsulas (Pods):** Coloque la cápsula **directo en el tambor** antes de la ropa. *¡Nunca en el cajón!*

3 INICIO • SENSOR INTELIGENTE AI DD™ — AUTOMÁTICO

Cargue la ropa y cierre bien la puerta (se bloquea sola). Deje en **Normal (AI DD)**. El tambor gira unos segundos para pesar la ropa y detectar el tipo de tela, optimizando agua y lavado. Presione **Inicio/Pausa (▶||)**.

4 SECADORA • ALERTA DE CAPACIDAD (11 KG) — MÁX 2/3 TAMBOR

El tambor de secado es la mitad del tamaño de lavado. **¡No sobrecargar!** No llene por encima de las dos aletas superiores. Si lavó una carga muy grande, divídala en dos tandas de secado para un resultado rápido y esponjoso.

5 FILTRO DE PELUSAS • LIMPIAR SIEMPRE — OBLIGATORIO

Extraiga el filtro de pelusas ubicado en el marco inferior de la puerta de la secadora. Retire las pelusas con los dedos e insértelo firmemente antes de secar. Un filtro limpio evita sobrecalentamiento y reduce a la mitad el tiempo.

6 HUMEDAD DE LIMA • EVITAR OLORES — ENTREABIERTA

Lima tiene alta humedad costera. Al terminar sus lavados, pase una toalla seca por el jebe gris de la puerta y **deje la puerta de la lavadora ligeramente entreabierta** para que ventile y no genere humedad ni olores.

RECOMMENDED EVERYDAY CYCLES • CICLOS RECOMENDADOS

press cycle button on center panel

NORMAL (AI DD)	SPEED WASH	HEAVY / TOWELS	DELICATES
Daily cottons, shirts, casuals (auto sensing)	15–20 min quick rinse for lightly soiled items	Towels, jeans, heavy linens (deep spin)	Silk, activewear, fine synthetics (gentle)

Questions about laundry or detergent? / ¿Dudas con el lavado? WhatsApp Silvia: +1 (954) 907-5730
We provide starter laundry detergent for your stay. Please contact us if you need assistance! • Conserjería 24h.

♡ **THANK YOU FOR CARING FOR OUR HOME • ¡MUCHAS GRACIAS POR CUIDAR NUESTRA CASA!**

SILVIA • LILY PAD VACATION RENTALS MIRAFLORES